

# POKYNY PRO MONTÁŽ

INSTALLATION GUIDELINE  
VERLEGEANLEITUNG

## REGUPOL vibration

---



200



300




400




450




480




550



800



1000



platí pouze pro  
REGUPOL vibration 200

